Care and Maintenance of ChamClad® Exterior Wall Panels

ChamClad® products are designed to be low maintenance and our Laminate Films have exceptional properties that ensure ease of cleaning and surface longevity. They are highly ultra-violet, pollution, and salt air resistant. The film's low surface tension makes it inherently dirt-repellent and therefore easy to clean. ChamClad® finishes include anti-graffiti properties and in most cases can be easily removed with a mild kitchen detergent and warm water. Should you experience removal difficulties, please contact us at info@chamclad.com.

In normal or urban environments, where atmosphere is considered to have low pollutants, we recommend cleaning every 12-18 months. In areas subject to high-pollutants such as industrial or coastal environments, we recommend cleaning more frequently – every 8-12 months.

- Using a soft bristled nylon brush attached to a garden hose, clean the surface with a mild PH neutral soap or non-abrasive kitchen detergent in warm water. DO NOT USE abrasive, erosive, or caustic solvents to clean ChamClad® panels as they can damage the panel finish and will void the warranty.

- To avoid streaking start at the top of the wall – working your way to the bottom.

- Follow with a thorough rinsing of fresh water to ensure that substances such as airborne salts, dirt and pollutants are removed.

- Always remove unintentional paint splashes, stucco spills, etc. immediately to prevent the possibility of permanent staining.

- Do NOT pressure wash as this could damage the protective coating layers of ChamClad® Exterior wall panels and will void the Warranty.

Provided that Regular Care and Maintenance practices are followed, ChamClad® Exterior wall panels will provide long term performance and protect your investment.